

Listed below are a number of nuts and bolts for which it has been found necessary to determine torque settings. It is most important that these settings are strictly adhered to. Over-tightening or non-uniform tightening of the cylinder head and barrel nuts for instance, can cause distortion, resulting in loss of compression, increased engine wear and poor fuel economy.

Application	Thread Diameter and Form	T.p. i.	Hexagon A/F	TORQUE SETTINGS	
				Foot Pounds	Kilogram- metres
Carburettor stud nuts	0.3125" B.S.C.	26	0.525"	10/12	1.383/1.659
Clutch centre nut	0.50" B.S.F.	16	0.820"	40/49	5.530/5.945
Cylinder head & barrel stud nuts	0.3125" B.S.F.	22	0.525"	18/20	2.489/2.765
Fork leg pinch bolts	0.3125" B.S.F.	22	0.525"	14/16	1.936/2.212
Gearbox sprocket nut	0.8750" W.F. (L/H)	20	1.200"	50/55	6.913/7.604
Rotor fixing nut	0.6250" B.S.C.	20	1.010"	55/60	7.604/8.295
Stator fixing nuts	0.250" B.S.F.	26	0.445"	6/8	0.830/1.106
Steering column pinch bolt	0.3125" B.S.F.	22	0.525"	14/16	1.936/2.212

Abbreviations: A/F Across Flats. L/H Left-hand Thread.
 B.S.C. British Standard Cycle. T.P.I. Threads Per Inch.
 B.S.F. British Standard Fine. W.F. Whitworth Form.

CHEMICAL LOCKS

The use of "Loctite AVV Red" is recommended on the clutch centre nut.

TORQUE WRENCH EXTENSIONS

The torque figures listed overleaf, indicate the load exerted at the end of a torque wrench. In some cases where space is restricted, the direct application of a torque wrench may be found impossible and a suitable extension or adaptor must be used.

When using an extension however, the wrench dial reading must be altered according to the following formula, in order to achieve the recommended torque load.

$$\text{Wrench dial reading} = \frac{\text{Recommended torque load} \times \text{length of torque wrench (in.)}}{\text{Length of torque wrench (in.)} \times \text{length of extension (in.)}}$$

For example:—To obtain a torque load of 30 lb./ft. when using a two foot long wrench with a six inch extension, the dial reading would be calculated in the following manner:—

$$\text{Wrench dial reading} = \frac{30 \times 24}{24 \times 6} \quad \text{Therefore} \quad = \quad 24 \text{ lb./ft.}$$